



INSTRUCCIONES DE MONTAJE ASSEMBLING INSTRUCTIONS



439961



INSTRUCTIONS D'ASSEMBLAGE
ISTRUZIONI PER IL MONTAGGIO
INSTRUÇÕES DE MONTAGEM
MONTAGEANLEITUNG

ATENCIÓN: Schuller recomienda que utilice los balancines suministrados en la instalación de esta lámpara.

ATENCIÓN

Artículo muy pesado (20 Kg).
Realizar un anclaje seguro.




El montaje y la manipulación de este artículo debe hacerse entre **dos personas**.

Ajustar la longitud de los cables sin la tulipa antes de instalar. (Paso 2)

Colocar las tulipas después de instalar la lámpara al techo en su posición definitiva.


NOTA IMPORTANTE


Para corregir la torsión natural del cable, frotarlo con un destornillador o una varilla rígida, como indica la figura.



LA FABRICACIÓN ARTESANAL DE ESTA TULIPA DE CRISTAL PERMITE LIGERAS IMPERFECCIONES ACEPTADAS POR NUESTRO CONTROL DE CALIDAD.

Para ver la ficha técnica de producto completa, puede usar el siguiente código QR:






Medidas de cables para configurar lámpara a 500cm. (el diseño de la lámpara quedará igual al dibujo / fotografía de web).

Para otras medidas, tomar estas como referencia

 **Ø10 cm**
9 uds

 **Ø12 cm**
9 uds

 **Ø20 cm**
7 uds

A- Ø20 - H:500 cm - AMBAR

B1- Ø10 - H:450 cm - SMOKE

B2- Ø12 - H:425 cm - SMOKE

B3- Ø10 - H:280 cm - AMBAR

B4- Ø12 - H:320 cm - SMOKE

B5- Ø10 - H:395 cm - AMBAR

B6- Ø12 - H:375 cm - AMBAR

C1- Ø12 - H:405 cm - SMOKE

C2- Ø10 - H:355 cm - SMOKE

C3- Ø12 - H:410 cm - AMBAR

C4- Ø10 - H:475 cm - AMBAR

C5- Ø12 - H:450 cm - SMOKE

C6- Ø10 - H:415 cm - AMBAR

D1- Ø10 - H:380 cm - AMBAR

D2- Ø20 - H:330 cm - AMBAR

D3- Ø12 - H:305 cm - SMOKE

D4- Ø20 - H:375 cm - SMOKE

D5- Ø10 - H:325 cm - AMBAR

D6- Ø20 - H:440 cm - AMBAR

D7- Ø12 - H:350 cm - AMBAR


D8- Ø20 - H:400 cm - SMOKE

D9- Ø10 - H:360 cm - SMOKE

D10- Ø20 - H:295 cm - AMBAR

D11- Ø12 - H:380 cm - AMBAR

D12- Ø20 - H:350 cm - SMOKE






Schuller®

600637
TRIAC DIMMER


INSTALACIÓN 1

Simplificada dentro del florón




INSTALACIÓN 2

Dimado a través de pulsador dentro del florón



Schuller®

600620 MANDO A DISTANCIA.
INSTRUCCIONES DE MANEJO.



1. Encendido general.
2. Apagado general
3. Aumentar la luminosidad progresivamente.
4. Reducir la luminosidad progresivamente.
5. 4 Canales. Una vez encendida la lámpara y antes de 5 segundos, elegir canal y mantener pulsado el botón (1, 2, 3 ó 4). El parpadeo indicará que se ha guardado el ajuste de luz en el botón (canal) pulsado.
6. Encendido selectivo. (Sólo enciende el canal pulsado)
7. Apagado selectivo. (Sólo apaga el canal pulsado)

NOTA: Para borrado general de canales, pulsar hasta el parpadeo el botón UNLINK del dimmer instalado.

Para cualquier duda técnica póngase en contacto con nuestro Departamento Técnico.
Estamos a su servicio en nuestro email mperez@schuller.es o en nuestro teléfono 961 601 051

ATTENTION: Schuller recommends to use included special screws when installing this pendant lamp.

WARNING

Very heavy item (20 kgs).
Make sure it is properly fixed




The assembly of this lamp must be done by **two people**

Adjust the length of the cables without glass shade before installing. (Step 2)

After the lamp has been installed in its final position on the ceiling, fit the lampshades.


IMPORTANT NOTICE:


If the cable is twisted, please hold the bottom of the cable, and use a screwdriver or a metal rod to stroke the cable up and down to keep it straight.



CRAFTMAN PRODUCTION FOR
THIS GLASS SHADE ALLOW SMALL
IMPERFECTIONS CHECKED BY OUR
QUALITY CONTROL


You may use the following QR code to view the complete technical data sheet of the product:





Cable sizes to set the lamp at 500 cm (the design of the lamp will be the same as the rawing/photograph on the website)

For other settings take these as a reference.



A- Ø20 - H:500 cm - AMBAR

B1- Ø10 - H:450 cm - SMOKE

B2- Ø12 - H:425 cm - SMOKE

B3- Ø10 - H:280 cm - AMBAR

B4- Ø12 - H:320 cm - SMOKE

B5- Ø10 - H:395 cm - AMBAR

B6- Ø12 - H:375 cm - AMBAR

C1- Ø12 - H:405 cm - SMOKE

C2- Ø10 - H:355 cm - SMOKE

C3- Ø12 - H:410 cm - AMBAR

C4- Ø10 - H:475 cm - AMBAR

C5- Ø12 - H:450 cm - SMOKE

C6- Ø10 - H:415 cm - AMBAR

D1- Ø10 - H:380 cm - AMBAR

D2- Ø20 - H:330 cm - AMBAR

D3- Ø12 - H:305 cm - SMOKE

D4- Ø20 - H:375 cm - SMOKE

D5- Ø10 - H:325 cm - AMBAR

D6- Ø20 - H:440 cm - AMBAR

D7- Ø12 - H:350 cm - AMBAR


D8- Ø20 - H:400 cm - SMOKE

D9- Ø10 - H:360 cm - SMOKE

D10- Ø20 - H:295 cm - AMBAR


D11- Ø12 - H:380 cm - AMBAR

D12- Ø20 - H:350 cm - SMOKE





INSTALATION 1

Simplified. Inside the canopy.



INSTALATION 2

Dimmed by push button. Inside the canopy.



1. General switch on.
2. General switch off.
3. Increase brightness gradually.
4. Reduce brightness gradually.
5. 4 channels. Once the lamp is switched on and within 5 seconds, select a channel and press and hold the button (1, 2, 3 or 4). The flashing light indicates that the light setting has been saved to the button (channel) pressed.
6. Selective switch-on. (Only switches on the pressed channel)
7. Selective switch-off. (Only switches off the pressed channel)

NOTE: To delete all channels, press and hold the UN-LINK button on the installed dimmer until it flashes.

If you have any technical questions, please do not hesitate to contact our technical Department.
We are at your disposal in our email: export@schuller.es